

Forget-Me-Not Valet

Base Drilling Template Set

v1.0

October 2014
by Sean Michael Ragan
for littleBits, Inc.

- Print on adhesive backed mailing label and cut out five (5) templates.
- Removing backing, align solid lines to edges or corners indicated, and affix.
- Start each hole at crossed lines with 1/8" brad-point drill bit.
- Drill out gray area to finish diameter with panel/step drill bit.
- Unless otherwise indicated, all finish diameters are 1/4".
- For full instructions visit: littlebits.cc/projects/forget-me-not-valet

