























### (C) SPEAKER MOUNT



### (E) CONTROL PANEL PLATE



### (B) CARD READER



### (A) CASE

### (D) FACE PLATES